

Septembre 2025

Mise à jour micrologiciel de l'imprimante DS620

- Un nouveau micrologiciel (Firmware) est disponible pour les imprimantes DNP modèles DS620 en version 4.33
- Disponible uniquement d'après OS windows 10 (32/64bits) windows 11 (32/64 bits)

Procédure de mise à jour :



NE PAS DEBRANCHER NI ETEINDRE LA DS620 PENDANT LA MISE A JOUR

Télécharger le firmware sur le lien suivant :

https://www.dnpphoto.eu/fr/telechargements/pilotes-et-outils/firmwares-sofwarees/ds620-4/876-ds620-firmware-v-4-31-1/file?accept_license=1

- Allumer la DS620 et la connecter au PC avec le câble USB, puis décharger le papier et refermer le tiroir.
- Double cliquer sur le fichier DP-DS620 (DP-DS620_0433x86_Direct.exe) pour le système d'exploitation 32 bits.*
Double cliquer sur le fichier DP-DS620 (DP-DS620_0433x64_Direct.exe) pour le système d'exploitation 64 bits.*
- Suivre les instructions selon les fenêtres affichées

Etape 1 : Cliquer sur START

DP-DS620 Version Up Tool

New Firmware Ver ☐ DS620 04.33
Printer Firm Ver ☒ DS620 04.32

SD CWD Ver 300	☒	DS620_SD_300_0111.CWD	Sum	28B7
SD CWD Ver 600	☒	DS620_SD_600_0111.CWD	Sum	FD22
SD CWD Ver Slow	☒	DS620_SD_610_0111.CWD	Sum	5479
PD CWD Ver 300	☒	DS620_PD_300_0111.CWD	Sum	28B8
PD CWD Ver 600	☒	DS620_PD_600_0111.CWD	Sum	FD23
PD CWD Ver Slow	☒	DS620_PD_610_0111.CWD	Sum	547A

** Firmware Update ** Push START button.

Status

☐ Transmitting data is prepared.

☐ The printer changes to the rewrite mode.

☐ Firmware is transmitted.

☐ Firmware is written in flash ROM.

☐ CWD data is transmitted and written.

START

END

CAUTION:
While updating, do not disconnect the USB cable or turn the power off.
Do not perform any operations such that could result in an error, such as opening the printer cover.
Also, do not start or run other software at the same time.

Etape 2 : La mise à jour commence

DP-DS620 Version Up Tool

New Firmware Ver ☐ DS620 04.33
Printer Firm Ver ☒ DS620 04.32

SD CWD Ver 300	☒	DS620_SD_300_0111.CWD	Sum	28B7
SD CWD Ver 600	☒	DS620_SD_600_0111.CWD	Sum	FD22
SD CWD Ver Slow	☒	DS620_SD_610_0111.CWD	Sum	5479
PD CWD Ver 300	☒	DS620_PD_300_0111.CWD	Sum	28B8
PD CWD Ver 600	☒	DS620_PD_600_0111.CWD	Sum	FD23
PD CWD Ver Slow	☒	DS620_PD_610_0111.CWD	Sum	547A

** Complete ** Push END button.

Status

☒ Transmitting data is prepared.

☒ The printer changes to the rewrite mode.

☒ Firmware is transmitted.

☒ Firmware is written in flash ROM.

☒ CWD data is transmitted and written.

START

END

CAUTION:
While updating, do not disconnect the USB cable or turn the power off.
Do not perform any operations such that could result in an error, such as opening the printer cover.
Also, do not start or run other software at the same time.

Etape 3 : Fin de la mise à jour

DP-DS620 Version Up Tool

New Firmware Ver ☒ DS620 04.33
Printer Firm Ver ☒ DS620 04.32

SD CWD Ver 300	☒	DS620_SD_300_0111.CWD	Sum	28B7
SD CWD Ver 600	☒	DS620_SD_600_0111.CWD	Sum	FD22
SD CWD Ver Slow	☒	DS620_SD_610_0111.CWD	Sum	5479
PD CWD Ver 300	☒	DS620_PD_300_0111.CWD	Sum	28B8
PD CWD Ver 600	☒	DS620_PD_600_0111.CWD	Sum	FD23
PD CWD Ver Slow	☒	DS620_PD_610_0111.CWD	Sum	547A

** Complete ** Push END button.

Status

☒ Transmitting data is prepared.

☒ The printer changes to the rewrite mode.

☒ Firmware is transmitted.

☒ Firmware is written in flash ROM.

☒ CWD data is transmitted and written.

START

END

CAUTION:
While updating, do not disconnect the USB cable or turn the power off.
Do not perform any operations such that could result in an error, such as opening the printer cover.
Also, do not start or run other software at the same time.

Etape 4 : une fois la mise à jour terminée, éteindre et rallumer le PC pour valider les nouvelles fonctionnalités

Etape 5 : Charger le papier imprimante allumée afin de régler l'équilibre du capteur de ruban

***Pour les DS620 connectés sur l'OS MAC, faire la mise à jour sur un PC impérativement**